

INSTALLATION GUIDE FOR DÉCOR STAND


1. Remove the bulb and the cover.



2. Place Décor 30 to Décor stand.
3. If the screw cannot fit in the hole, please use screwdriver to clean the excess paint at the hole.



BACK



FRONT

4. Tighten the screw, install back the cover and bulb. Then it is ready to display.

5. Option: Bottom cover – use the 2 small screw to install the cover.

